



***bajadesigns***<sup>®</sup>  
THE SCIENTISTS OF LIGHTING

**24-on Can-Am, Maverick R, S2 Sport Chase Light Kit  
(44-8223)**



2950 Norman Strasse San Marcos, CA 92069

Phone 760-560-2252 X3 • Fax 760-560-0383

info@bajadesigns.com • [www.bajadesigns.com](http://www.bajadesigns.com)



**baja designs**<sup>®</sup>  
THE SCIENTISTS OF LIGHTING

## LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

### **Exclusions:**

Installation errors, abuse, misuse, or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace it with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

### **Indemnification:**

**Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.**


**Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.**

**\*\*For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com \*\***

**Required Tool(s):**


- 10mm, 13mm wrench
- 10mm, 13mm, 18mm, 5/8 socket

**Parts List:**

 <p><b>(54-0016) (QTY: 1)</b> S2 Sport, LED Work/Scene, Amber</p>	 <p><b>(64-0312) (QTY: 1)</b> Wiring Harness, Can-Am, Maverick R, Squadron/S2/S1 2- Light</p>	 <p><b>(20-1129) (QTY: 1)</b> Hardware, M6-1.0 x 60 Metric Flange Bolt</p>	 <p><b>(20-1690) (QTY: 1)</b> Hardware, M6 Nylock nut 18-8 SS</p>
 <p><b>(20-1282) (QTY: 1)</b> Hardware, 1/4 Flat Washer SS</p>	 <p><b>(20-9155) (QTY: 1)</b> Hardware, Spacer, .75" OD, 1.75 Long, M8 Screw Size</p>	 <p><b>(20-1612) (QTY: 12)</b> Hardware, Zip Tie 50lb 8"</p>	


To begin, make sure the vehicle is in park, on level ground and the parking brake is engaged.

**Step 1:**



Using a 5/8 socket, remove the driver side seat belt bolt securing the coiled cable and seat belt to the seat. Take the seat belt out through the shoulder hole.

**Step 2:**



To remove the front seat, use a 13mm wrench and socket to remove the front bolts (1). Use a 18mm socket to remove the rear seat nuts (2) from the studs. Lift the seat up and out to remove.

**Step 3:**



Remove the battery cover by pulling outward from the top. Using a 10mm wrench, remove the negative battery cable followed by the positive.

**Step 4:**



Place the M6 flange bolt through the universal bracket and attach the bracket to the S2 using the included parts bag.

**Step 5:**



Place the 1.75" spacer on the M6 bolt and slide the bolt through the B-Pillar. Secure it with the ¼" washer and M6 nylock nut. Tighten using the 10mm wrench and socket.

### Step 6:



Pull up on the center console top lid to remove. Take a photo of the switch wiring and remove the spade connectors from the rocker switch. (Harnesses with the quick connector do not require depinning the spade connector.) Run the switch lead from under the driver seat through the brake line passthrough and into the console. Press out a switch blank on the console top panel and run the switch wires through. Plug them into the switch and press the switch into place. Replace the center console top panel.

### Step 7:





Reattach the positive cable of battery and the positive ring terminal of the harness. Repeat with the negative cables. Use zip ties to place one of the light leads into a small service loop. Run the second lead out of the battery compartment, up the firewall and through the pass through (circled). Plug the connector into the light and secure the wiring with zip ties. Bundle excess wires and secure in the battery tray.

**Step 8:**



Replace battery cover and test the light to ensure it functions correctly.

**Step 9:**



Replace the driver seat. Tighten the rear nuts (2) to 48ft-lbs and the front nut and bolts (1) to 18 ft-lbs. Reattach the lower seat belt point using the original routing. Ensure the plastic washer is between the bolt head and seat belt plate. Tighten the seat belt bolt to 48ft-lbs.

\*Tie all wires away from sharp, hot, and/or rotating components.

\* Re-torque all the fasteners after 100 miles.

\*Your install is now complete! Thank you for choosing Baja Designs.