



***bajadesigns***®  
THE SCIENTISTS OF LIGHTING

**2024-On, Toyota Tacoma Upfitter Harness  
(60-0101)**



2950 Norman Strasse San Marcos, CA 92069

Phone 760-560-2252 X3 • Fax 760-560-0383

info@bajadesigns.com • [www.bajadesigns.com](http://www.bajadesigns.com)



**baja designs**<sup>®</sup>  
THE SCIENTISTS OF LIGHTING

## LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

### **Exclusions:**

Installation errors, abuse, misuse, or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will, however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace it with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

### **Indemnification:**

**Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.**

**Buyer is responsible for ensuring that it uses the products (and its vehicle) in accordance with all applicable laws, regulations, guidelines, and standards of care. Buyer acknowledges that some products may only be used when off-roading, and Buyer will comply with all vehicle and road safety guidelines. Buyer is solely responsible for (and will indemnify and hold Bestop harmless for) any claims, losses, damages, fines, fees, costs, or other amounts arising out of Buyer's non-compliance with these provisions.**

**\*\*For a color copy of instructions, visit your vehicle specific application on BajaDesigns.com \*\***

**Required Tool(s):**

- 10mm Socket
- Sharp Blade
- Zip Ties

**Parts List:**



**(60-0101) (QTY:1)**  
2024-On Toyota Tacoma,  
Upfitter Harness

**To begin, make sure the vehicle is in park, on level ground and the parking brake is engaged.**

**Step 1: Vehicle Prep**

Disconnect the negative battery terminal on the vehicle battery using a 10mm socket.






## Step 2: Locate the OEM upfitter plug


Remove the OEM connector plug A from the harness behind the driver side headlight.

Location of auxiliary switch wire harness connectors:




- A** Engine compartment
- B** Cabin (behind trim panel)
- C** Engine compartment
- D** Rear frame

Powered Circuits:



## Step 3: Harness info.

Plug in the connector on the harness provided into the OEM connector pictured above "Upfitter OEM Connector (5 Wire)".



**\* OEM connector is tied away with black electrical tape\***


#### Step 4: Prep the toggle switch harness

Remove the switch lead from the standard Baja Designs wiring harness. (64-0139 pictured below as an example)



#### Step 5: Connect the standard harness

Connect the standard Baja Designs wiring harness to one of the individual white connectors on 60-0101 based on which Auxiliary switch is preferred.



Aux 1: Connect your harness to red wire (Baja Designs adapter) (Pictured above)

Aux 2: Connect your harness to yellow wire (Baja Designs adapter)

Aux 3: Connect your harness to white wire (Baja Designs adapter)


### Step 6: Connect the lights

Connect your lights to the light lead on the standard harness. See Step 4.

**This step may vary if using a Baja Designs Vehicle Specific Kit.**

### Step 7: Re-connect the battery & additional ring terminals

Re-connect the vehicle battery using a 10mm socket. Attach the ring terminals from the Baja Designs standard harness to the vehicle battery using a 10mm socket.



### Step 7: Test the lights

Test your lights for proper functionality. Tie away any loose wires using zip ties. Installation complete!

\*Tie all wires away from sharp, hot, and/or rotating components.

\* Re-torque all the fasteners after 100 miles.

\*Your install is now complete! Thank you for choosing Baja Designs.